

6" spring filling valve



Product codes:

Reference:
PC170-00033
EAN13: -
UPC: -

Product attributes:

Product description:

When used with the F613 jet level sensor or F619B float operated pilot valve, fuel pressure provides the actuation force for opening and closing the valve during tank filling. The basic valve can be used for off-loading. Single or dual stage tank filling control is available by adding one or two pilot valves. A lug is provided for attachment of a lanyard to manually open the valve for emergency off-loading.